

Operating Instructions

(Read this manual carefully before using EdgeLight[®] Product)

Shanghai Edge Light Industry Co.,LTD.

TEL:+86-21-64412288

FAX:+86-21-64412266

[E-mail: info@cnelight.com](mailto:info@cnelight.com)

Published by EDGELIGHT Corporation

Copyright 2010 EDGELIGHT Corporation

All rights reserved.

Operating Instructions

Thank you for buying this EdgeLight® product. Please read through these operating instructions so you will know how to operate your unit properly. After you have finished reading the instructions, keep them in a safe place for future reference.

IMPORTANT



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Information to User

Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

Operating Instructions

SAFETY INSTRUCTIONS

To ensure your personal safety and to maximize the full operating potential of this product, read and follow these safety precautions:

ENVIRONMENT-DO NOT use the unit at places with high levels of dust or high temperature. Please use the unit in a place where it is not subjected to vibrations or shocks.

POWER- Please use correct power as required for this product.

READ INSTRUCTIONS-Read all safety and operating instructions before this product is operated.

RETAIN INSTRUCTIONS-Retain the safety and operating instructions for future reference.

FOLLOW INSTRUCTIONS-Follow all operating and use instructions.

HEED WARNINGS-All warnings must be adhered to.

CLEANING-DO NOT use aerosol cleaners. Use only a little alcohol or a damp cloth to clean the exterior housing.

POWER SOURCES- Operate this product from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult Authorized EdgeLight™ Dealer.

OVERLOADING-DO NOT overload wall outlets and extension cords. Doing so can result in fire or electric shock.

OBJECT AND LIQUID ENTRY-Never push objects of any kind into this product. Touching dangerous voltage points may cause a short resulting in fire or electric shock. Do not spill liquid of any kind on this product.

CONDENSATION-Moisture will form in the operating section of the product causing performance to be impaired if it is brought from cool surroundings into a warmer environment. If you are moving the unit to a location with a warmer temperature, let the product stand for 1 to 2 hours in the new location before turning it back on.

Operating Instructions

SPECIFICATIONS



AF11 SERIES

AF11 series slim light box is double viewing sides.

It is opened by key, this design can well protect AD graphic.

Item		Frame size	Viewing size	Thickn ess	Film size	Packing size	Volume	Gross weight	
		mm	mm		mm	mm			cm
AF11	T5		1800x1200	1700x1100	60	1728x1128	186x9x126	0.21	58.2
		B0	1494x1080	1398x984		1000x1414	162x9x121	0.18	42.2
		A0	1269x921	1173x825		1189x841	134x9x102	0.12	31
		A1	921x674	825x578		841x594	100x9x77	0.07	16.4
		A2	674x500	578x404		594x420	73x9x57	0.04	8.9
		Life span		Above 10000h					
	LED		1800x1200	1700x1100	60	1728x1128	186x9x126	0.21	58.2
		B0	1080x1494	984x1398		1414x100	134x9x102	0.12	42.2
		B1	1072x779	976x683		1000x707	114x9x85	0.09	22.1
		B2	779x572	683x476		707x500	84x9x65	0.05	11.8
		A0	1269x921	1173x825		1189x841	134x9x102	0.12	31
		A1	921x674	825x578		841x594	100x9x77	0.07	16.4
		A2	674x500	578x404		594x420	73x9x57	0.04	8.9
		Life span		Above 50000h					

INSTALLATION

Graphic Replacement

1. Turn off power
2. Open the front board by the key
3. Remove AD graphic from the front board
4. Change AD graphic
5. Lock the front board



is a trademark of Shanghai Edge Light Industry Co., Ltd

<http://www.cnedgelight.com>

Operating Instructions



Suspension

1. Measure installation dimension
2. Hang the light box in the right place
 - A. If the wall or ceiling is made of wood, plastic, aluminium and so on, you can directly hang the light box by lightboxes pendants
 - B. If the wall or ceiling is made of concrete, brick, marble and so on, you should firstly drill holes in the wall or ceiling and screw expand screws, and then hang the light box by lightboxes pendants.
3. Connect adapter
4. Connect the power supplier



Operating Instructions

ACCESSORIES

Operating instruction	x 1
Key	x 1
Adapter (AC100-240V)	x 1

(Various plugs are available for your needs, such as CE, UL, SAA, etc.)



CE



UL



SAA

NOTICE

- * Pay more attention that Slim Light Box not to be crashed. While transporting or working, keep sharp edge or instrument away from Slim Light Box . Use soft & wet textile to clean front board to avoid being scratched. Make sure to use right voltage.
- * Specifications and design subject to possible modifications without notice, due to improvements.

PLS download the more detailed user manual from the following website:
<http://www.cnedgelight.com/image/AF11 Series.pdf>



Printed in China