





## Operating Instructions

### SAFETY INSTRUCTIONS

To ensure your personal safety and to maximize the full operating potential of this product, read and follow these safety precautions:

**ENVIRONMENT-DO NOT** use the unit at places with high levels of dust, high temperature, or high humidity. Please use the unit in a place where it is not subjected to vibrations or shocks.

**POWER-** Please use correct power as required for this product.

**READ INSTRUCTIONS-**Read all safety and operating instructions before this product is operated.

**RETAIN INSTRUCTIONS-**Retain the safety and operating instructions for future reference.

**FOLLOW INSTRUCTIONS-**Follow all operating and use instructions.

**HEED WARNINGS-**All warnings must be adhered to.

**CLEANING-DO NOT** use aerosol cleaners. Use only a little alcohol or a damp cloth to clean the exterior housing.

**WATER AND MOISTURE-DO NOT** use the product near water.

**POWER SOURCES-** Operate this product from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult Authorized EdgeLight® Dealer.

**OVERLOADING-DO NOT** overload wall outlets and extension cords. Doing so can result in fire or electric shock.

**OBJECT AND LIQUID ENTRY-**Never push objects of any kind into this product. Touching dangerous voltage points may cause a short resulting in fire or electric shock. Do not spill liquid of any kind on this product.

**CONDENSATION-**Moisture will form in the operating section of the product causing performance to be impaired if it is brought from cool surroundings into a warmer environment. If you are moving the unit to a location with a warmer temperature, let the product stand for 1 to 2 hours in the new location before turning it back on.

# Operating Instructions

## SPECIFICATIONS



### AF18 Type

Item			Frame size	Viewing size	Thickness	canvas size	Packing size	Volume	Gross weight
			mm	mm		mm	mm		
AF18	LED	A4	297x210	291x204	33	318x231	50x5x30	0.01	0.8
		A3	420x297	414x291		441x318	58x9x46	0.01	1.7
		A2	594x420	588x414		615x441	73x9x57	0.01	3.3
		A1	841x594	835x588		862x615	100x9x77	0.02	6.6
		A0	1189x841	1183x835		1210x862	134x9x102	0.03	13.2
		B2	707x500	701x494		728x521	78x9x57	0.01	4.7
		B1	1000x707	994x701		1021x728	107x9x78	0.02	9.4
		B0	1414x1000	1408x994		1435x1021	162x9x121	0.05	18.7
		使用寿命	50000h以上						



## INSTALLATION

### Graphic Replacement

1. Turn off power
2. out of the canvas
3. insert the canvas



# Operating Instructions

Please see as follows:



## On the Wall

1. Measure installation dimension
2. Fix the light box on the wall by screws
  - A. If the wall is made of wood, plastic, aluminium and so on, you can directly fix the light box on the wall by self-tapping screws
  - B. If the wall is made of concrete, brick, marble and so on, you should firstly drill holes in the wall and screw expand screws, and then fix the light box.
3. Connect the power supplier



# Operating Instructions

## ACCESSORIES

Operating instruction	x 1
Power supply (AC100-240V)	x 1

(Various plugs are available for your needs, such as CE, UL, SAA, etc.)



CE



UL



SAA

## NOTICE

\* Pay more attention that Slim Light Box not to be crashed. While transporting or working, keep sharp edge or instrument away from Slim Light Box . Use soft & wet textile to clean front board to avoid being scratched. Make sure to use right voltage.

\*Specifications and design subject to possible modifications without notice, due to improvements.

PLS download the more detailed user manual from the following website:  
<http://www.cnedgelight.com/image/AF2 Series.pdf>

