

Operating Instructions



ACCESSORIES

Operating instruction x 1

Power supply (AC100-240V) x 1

(Various plugs are available for your needs, such as CE, UL, SAA, etc.)



CE



UL



SAA

NOTICE

- * Pay more attention that Slim Light Box not to be crashed. While transporting or working, keep sharp edge or instrument away from Slim Light Box. Use soft & wet textile to clean front board to avoid being scratched. Make sure to use right voltage.
- * Specifications and design subject to possible modifications without notice, due to improvements.

PLS download the more detailed user manual from the following website:

http://www.cnedgelight.com/image/AF2_Series.pdf



Printed in China

EdgeLight®

EdgeLight®



EdgeLight®

EdgeLight®

EdgeLight®

EdgeLight®

EdgeLight®

EdgeLight®