

Operating Instructions

(Read this manual carefully before using EdgeLight[®] Product)

Shanghai Edge Light Industry Co.,LTD.

TEL:+86-21-64412288

FAX:+86-21-64412266

[E-mail: info@cnelight.com](mailto:info@cnelight.com)

Published by EDGELIGHT Corporation

Copyright 2010 EDGELIGHT Corporation

All rights reserved.

Operating Instructions

Thank you for buying this EdgeLight® product. Please read through these operating instructions so you will know how to operate your unit properly. After you have finished reading the instructions, keep them in a safe place for future reference.

WARNING

This product is not waterproof. To prevent a fire or shock hazard, do not place any container filled with liquid near this equipment or expose it to dripping, splashing, rain or moisture.

IMPORTANT



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the

Information to User

Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

Operating Instructions

SAFETY INSTRUCTIONS

To ensure your personal safety and to maximize the full operating potential of this product, read and follow these safety precautions:

ENVIRONMENT-DO NOT use the unit at places with high levels of dust, high temperature, or high humidity. Please use the unit in a place where it is not subjected to vibrations or shocks.

POWER- Please use correct power as required for this product.

READ INSTRUCTIONS-Read all safety and operating instructions before this product is operated.

RETAIN INSTRUCTIONS-Retain the safety and operating instructions for future reference.

FOLLOW INSTRUCTIONS-Follow all operating and use instructions.

HEED WARNINGS-All warnings must be adhered to.

CLEANING-DO NOT use aerosol cleaners. Use only a little alcohol or a damp cloth to clean the exterior housing.

WATER AND MOISTURE-DO NOT use this product near water.

POWER SOURCES- Operate this product from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult


OVERLOADING-DO NOT overload wall outlets and extension cords. Doing so can result in fire or electric shock.

OBJECT AND LIQUID ENTRY-Never push objects of any kind into this product. Touching dangerous voltage points may cause a short resulting in fire or electric shock. Do not spill liquid of any kind on this product.

CONDENSATION-Moisture will form in the operating section of the product causing performance to be impaired if it is brought from cool surroundings into a warmer environment. If you are moving the unit to a location with a warmer temperature, let the product stand for 1 to 2 hours in the new location before turning it back on.

Operating Instructions

SPECIFICATIONS



AF4 SERIES

Item		Frame size	Viewing size	Thickness	Film size	Packing size	Volume	Gross weight	
		mm	mm		mm	mm			cm
AF4	T5		2400x1200	2288x1088	33	2309*1120	246*9*126	0.28	40
			1800x1200	1688x1088		1709*1120	186*9*126	0.21	32
		B0	1505x1097	1393x985		1414*1000	162*9*121	0.18	24.3
		A0	1280x938	1168x826		1189*841	134*9*102	0.12	16.2
		A1	932x691	820x579		841*594	100*9*77	0.07	9.8
		A2	685x517	573x405		594*420	73*9*57	0.04	7
		Life span		Above10000h					
AF4	LED		2400x1200	2288x1088	33	2309*1103	246*9*126	0.28	40
			1800x1200	1688x1088		1709*1103	186*9*126	0.21	32
		B0	1505x1080	1393x968		1414*1000	162*9*121	0.18	24.3
		B1	1091x787	979x675		1000*707	114*9*85	0.09	12.9
		B2	591x787	479x675		707*500	84*9*65	0.05	24.3
		A0	1280x921	1168 x 809		1189*841	134*9*102	0.12	16.2
		A1	685x921	573x809		841*594	100*9*77	0.07	9.8
		A2	511x674	399x562		594*420	73*9*57	0.04	7
		Life span		Above50000h					

Graphic Replacement

1. Turn off power
2. Open the four upper covers
3. Remove front board and AD graphic
4. Change AD graphic
5. Place back the front board
6. Close the four upper cover

Please see as follows:

Operating Instructions




On the Wall

1. Measure installation dimension
2. Fix the light box on the wall by screws
 - A. If the wall is made of wood, plastic, aluminium and so on, you can directly fix the light box on the wall by self-tapping screws
 - B. If the wall is made of concrete, brick, marble and so on, you should firstly drill holes in the wall and screw expand screws, and then fix the light box.
3. Connect the power supplier



Operating Instructions



ACCESSORIES

Operating instruction x 1

Power supply (AC100-240V) x 1

(Various plugs are available for your needs, such as CE, UL, SAA, etc.)



CE



UL



SAA

NOTICE

- * Pay more attention that Slim Light Box not to be crashed. While transporting or working, keep sharp edge or instrument away from Slim Light Box. Use soft & wet textile to clean front board to avoid being scratched. Make sure to use right voltage.
- * Specifications and design subject to possible modifications without notice, due to improvements

PLS download the more detailed user manual from the following website:

<http://www.cnedgelight.com/image/AF4 Series.pdf>



Printed in China