

Operating Instructions

(Read this manual carefully before using EDGELIGHT™ Product)

Shanghai Edge Light Industry Co.,LTD.

Add:3301 South Hongmei Rd., Minhang District,
Shanghai, China ZIP:201108

TEL:+86-21-64412288

FAX:+86-21-64412266

E-mail: info@cnedgelight.com

Published by EDGELIGHT Corporation

Copyright 2008 EDGELIGHT Corporation

All rights reserved.

Operating Instructions

Thank you for buying this EDGELIGHT™ product. Please read through these operating instructions so you will know how to operate your unit properly. After you have finished reading the instructions, keep them in a safe place for future reference.

WARNING

This product is not waterproof. To prevent a fire or shock hazard, do not place any container filled with liquid near this equipment or expose it to dripping, splashing, rain or moisture.

IMPORTANT



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric sh

**CAUTION
DO NOT OPEN**

CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

INFORMATION TO USER

Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

Operating Instructions

SAFETY INSTRUCTIONS

To ensure your personal safety and to maximize the full operating potential of your Drive, read and follow these safety precautions:

ENVIRONMENT-DO NOT use the unit at places with high levels of dust, high temperature, or high humidity. Please use the unit in a place where it is not subjected to vibrations or shocks.

POWER- Please use correct power as required for this product.

READ INSTRUCTIONS- Read all safety and operating instructions before the Drive is operated.

RETAIN INSTRUCTIONS- Retain the safety and operating instructions for future reference.

FOLLOW INSTRUCTIONS- Follow all operating and use instructions.

HEED WARNINGS-All warnings must be adhered to.

CLEANING-DO NOT use liquid, aerosol cleaners, or alcohol. Use only a damp cloth to clean the exterior housing.

WATER AND MOISTURE-DO NOT use this product near water.

POWER SOURCES- Operate this product from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult Authorized EDGELIGHT™ Dealer.

OVERLOADING-DO NOT overload wall outlets and extension cords. Doing so can result in fire or electric shock.

OBJECT AND LIQUID ENTRY- Never push objects of any kind into this product. Touching dangerous voltage points may cause a short resulting in fire or electric shock. Do not spill liquid of any kind on this product.

CONDENSATION- Moisture will form in the operating section of the product causing performance to be impaired if it is brought from cool surroundings into a warmer environment. If you are moving the unit to a location with a warmer temperature, let the product stand for 1 to 2 hours in the new location before turning it back on.

Operating Instructions

SPECIFICATIONS



CF1-A4



CF1-B6

Item No	CF1-A4	CF1-B6
Viewing sides	Single	Single
Frame size	298x385mm	159x212mm
Thickness	8mm	8mm
Viewing size	200x287mm	129x182mm
Image size	210x297mm	129x182mm
Packing size	596x45x404mm	350x50x220mm
G.W	1.8kgs	0.8kgs
Light source	LED	LED
Power supply	DC 12V 1A	DC 12V 1A
Power	4W	2W
Life span	Above 50000h	

INSTALLATION

Graphic Replacement



Unscrew the bolts and remove the board




Place image on front board



Add the front board and screw bolts

A: On Desk

1. Unscrew two AD nails
2. Lock the standing legs
3. Connect the adapter
4. Connect the power supplier



CF1-A4



CF1-B6

Operating Instructions

B: On the wall (available for CF1-A4)

1. Measure installation dimension
2. Drive AD nuts in the wall
3. Fix light box and screw the AD nails
4. Connect the adapter
5. Connect the power supplier



On the wall

ACCESSORIES

Operating instruction	x 1
AD nail	x 4
Standing leg	x 2
Power supplier (AC100-240V)	x 1

(Various plugs are available for your needs, such as CE, UL, SAA, etc)



CE



UL



SAA

NOTICE

- * Pay more attention that Slim Light Box not to be crashed. While transporting or working, keep sharp edge or instrument away from Slim Light Box. Use soft & wet textile to clean front board to avoid being scratched. Make sure to use right voltage.
- * Specifications and design subject to possible modifications without notice, due to improvements.

PLS download the more detailed user manual from the following website:

<http://www.cnedgelight.com/image/cf1-a4&b6.pdf>



Printed in China